



# USAGI



NO	PARTS NUMBER	PARTS ITEM
1	SSWSWM4078	Lever Reach Adjuster
2	SSER15001	E-Retaining Ring
3	SPBH09020	Lever
4	SPBH01027	Lever Shift
5	SPBH01028	Push Rod
6	SPBH09018	Piston of Master Cylinder
	SSORP7000	P7 O-Ring
	SPBH09011	Cap of Master Cylinder Piston
	SSSP01003	Return Spring
7	SSSWM5084 SSSWM5085	Lever Pin
8	SSWS06110	Washer
9	SPBH01004	Reservoir Cap Screw


10	SPBH01025	Reservoir Plug
	SPBH010241	Reservoir Cap
11	SSSWM6105	Clamp Screw(M4*17.8mm)
12	SSWS04060	Stainless Steel Washer
13	SSSWM5086	Bleeding Screw
14	SPBH090235	Left Master Cylinder Body(BLACK)
	SPBH090235	Left Master Cylinder Body(BLACK)
15	SPBH090245	Right Master Cylinder Body(WHITE)
	SPBH090244	Right Master Cylinder Body(WHITE)



NO	PARTS NUMBER	PARTS ITEM
1	SPBH090155	Caliper Body(Inner WHITE)
	SPBH090154	Caliper Body(Inner BLACK)
2	SSSWM6106	Screw(M6*18.4)
3	SSPD40141	Pad(Inner)
4	SSPD40143	Pad Spring

5	SSPD40142	Pad(Outer)
---	-----------	------------

6	SPBH03050	Square Seal
	SPBH03017	Caliper Piston
7	SPBH01013	Caliper Seal
8	SPBH090145	Caliper Body (Outer WHITE)
	SPBH090144	Caliper Body (Outer BLACK)
9	SSSWM5086	Bleeding Screw
10	SSSWM4072	Pad Pin Fixed Screw
11	SPBH03005	Pad Pin
	SPBH09017	Cearmic Caliper Piston



NO	PARTS NUMBER	PARTS ITEM
1	SPBH01034	Hose Insert
2	SPBH01036	Hose Insert Sleeve
3	SPBH01038	Hose Nut
4	SPBH01043	Nose Cone
5	SPHSVTB01	PVC Hose(Black)